

# **MIDA NEROL**

Food grade polish and lubricant for the food industry and institutional hygiene

#### **DESCRIPTION & APPLICATION**

MIDA NEROL is a ready-to-use liquid product of oily consistence for treating of surfaces.

**MIDA NEROL** cleans and restores the shine to stainless steel and aluminium surfaces. For best results first degrease the surface then apply the undiluted product. Allow to act for a few moments then polish off with a clean cloth.

#### **USE INSTRUCTIONS**

**MIDA NEROL** is recommended for use in undiluted form. Apply with a soft and dry cloth in a thin layer of concentrate directly on the treated surface. Short-term (up to the 1 minute) is allowed to react and then polished-over to a high shine with clean dry cloth. Product is not rinse!

## PRODUCT CHARACTERISTICS

Composition	Contains special alcohols.
Appearance	Clear liquid
Colour	Colourless
Odour	Characteristic of the product
pH (1%)	± 7,5
Density	± 0,85 g/cm <sup>3</sup> (20°C)
Solubility	Miscible in water in all proportions

### **MATERIAL COMPACTIBILITY**

When **MIDA NEROL** is used according to the recommended use instructions, then **MIDA NEROL** can be used on materials commonly used in the food industry.

#### **ENVIRONMENT**

The surfactants of **MIDA NEROL** comply with the European Union Directive EU648/2004 on the biodegradability of surfactants.



#### **SAFETY**

Never mix **MIDA NEROL** with other products. Carefully read the material safety data sheet of **MIDA NEROL** and follow the chemical handling and disposal guidance.

# STORAGE

Store **MIDA NEROL** in its original packaging between 5°C and 25°C. Do not expose to direct sunlight. The expiry date is 24 months from date of manufacture.

#### PACKAGING

MIDA NEROL can be available in CAN.

Technical Data Sheet **MIDA NEROL** Revision 02.03.2018